



Smartline Vacuum Transmitter PROFINET Communication Manual



VSR/VCR/VSL/VCL/VSP/VCP



VSM/VS1



VSH

Version: 2.2
Release: June 03, 2025
Copyright: © 2025 Thyracont Vacuum Instruments GmbH

Content

1	Introduction / Product Description	4
1.1	Validity	4
1.2	Function	4
1.3	Installation	4
1.3.1	PROFINET address assignment	4
1.3.2	PROFINET device name	4
1.3.3	Projecting	4
1.3.4	Powering / Cabling	4
1.4	Communication	4
2	Modules	5
2.1	Input Modules	5
2.1.1	Actual Pressure	5
2.1.2	Relative Pressure	5
2.1.3	Actual GCF 1	6
2.1.4	Actual GCF 2	7
2.1.5	Transmitter Status and Type	8
2.1.6	Transmitter Warnings and Errors	10
2.1.7	Syntax Error	12
2.1.8	Command executed	13
2.2	Output Modules	14
2.2.1	Adjust Value Pressure	14
2.2.2	Set Data GCF 1	15
2.2.3	Set Data GCF 2	16
2.2.4	Set Data Sensor Switch Mode	17
2.2.5	Command	18
3	Commands	19
3.1	Command List	19
3.2	General Command Chain for all Smartline Transmitter	20
3.2.1	0x00 (0) – Zero Command	20
3.2.2	0x01 (1) – Adjust High Vacuum	20
3.2.3	0x02 (2) – Adjust Atmospheric Pressure	20
3.2.4	0x03 (3) – Set Gas Correction Factors	20
3.3	VSR/VCR Commands	21
3.3.1	0x39 (57) – Set Sensor Switch Mode	21
3.4	VSL/VCL Commands	21
3.4.1	0x04 (4) – Adjust Relative Pressure	21
3.4.2	0x39 (57) – Set Sensor Switch Mode	21
3.5	VSM/VSJ Commands	21
3.5.1	0x46 (70) – Activate Cold Cathode	21
3.5.2	0x47 (71) – Deactivate Cold Cathode	21
3.6	VSM Commands	21
3.6.1	0x4D (77) – Set Sensor Switch Mode	21
3.7	VSH Commands	22
3.7.1	0x50 (80) – Activate Hot Cathode	22
3.7.2	0x51 (81) – Deactivate Hot Cathode	22
3.7.3	0x55 (85) – Activate DeGas	22
3.7.4	0x56 (86) – Deactivate DeGas	22
3.7.5	0x57 (87) – Set Sensor Switch Mode	22
3.8	Acyclic Data Exchange	23
4	Device Diagnostics	24
4.1	Manufacturer Specific Channel Diagnosis	24
5	Web Interface	24

6	Additional Files (GSDML, Documentation)	24
7	Document History.....	25
8	License	25

1 Introduction / Product Description

1.1 Validity

This supplementary information describes important variations to the standard product and is only valid together with its main operation manual.

1.2 Function

The electrically isolated PROFINET IO-device interface is equipped with an integrated 2-port switch and supports 100 Mbit/s full duplex communication. The connection to a PROFINET system is possible via connections designated "PN P1" and "PN P2" (2 x M12, D-coded, 4pin, female).

1.3 Installation

1.3.1 PROFINET address assignment

Note: on delivery, the gauge has no IP address!

During normal operation (data exchange mode) the IP address is assigned to the device by the PROFINET IO-controller (PLC). For it the device has a device name on which it is addressed (see chapter [1.3.2](#)).

The IP address can be assigned manually or via a DHCP server.

1.3.2 PROFINET device name

Note: on delivery, the gauge has no device name!

The device name is assigned via the configuration software of the device.

1.3.3 Projecting

Use any project planning tool for project planning. You can download the GSDML files from the Thyracont webpage (<https://thyracont-vacuum.com/>).

Note: There was a rearrangement of the output modules 9 to 12 in GSDML-V2.42. Hence when updating from GSDML-V2.33 to GSDML-V2.42 or higher, please make sure to also adapt the module addresses on your PLC.

1.3.4 Powering / Cabling

Power is always supplied to the transmitter via the RS-485 connector (see operating instruction of the standard version). Make cabling in compliance with the valid regulations.

1.4 Communication

The device is parameterized and configured by the PROFINET IO-controller during startup phase. Only after a correct termination of the startup phase the data exchange with external devices will take place.

Communication is via cyclic and acyclic data exchange.

Input Data

- Input Modules

Commands

- Output Modules

2 Modules

2.1 Input Modules

2.1.1 Actual Pressure

Module ID=IDM_1: Actual Pressure				
Module Ident Number	0x00040000			
Information	Contains the actual pressure value. Note: A value of "2e-38" means pressure is below range limit, "2e+38" means pressure is above range limit.			
Category	Input modules			
Submodule ID=IDS_1: Actual Pressure				
Submodule Ident Number	0x00000001			
I&M 5 Supported	<input type="checkbox"/> No			
Cyclic Input Data				Item consistency
Name	Data Type	Display as Bits	Subordinate	Length [Bytes]
Actual Pressure	Float32	<input type="checkbox"/> No	<input type="checkbox"/> No	

Note: This module is also used for acyclic data exchange ([3.8](#)) and diagnosis data ([4.1](#)).

2.1.2 Relative Pressure

Module ID=IDM_13: Relative Pressure				
Module Ident Number	0x00040000			
Information	Contains the relative pressure value.			
Category	Input modules			
Submodule ID=IDS_13: Relative Pressure				
Submodule Ident Number	0x0000000D			
I&M 5 Supported	<input type="checkbox"/> No			
Cyclic Input Data				Item consistency
Name	Data Type	Display as Bits	Subordinate	Length [Bytes]
Relative Pressure	Float32	<input type="checkbox"/> No	<input type="checkbox"/> No	

2.1.3 Actual GCF 1

Module ID=IDM_2: Actual GCF 1				
Module Ident Number	0x00020000			
Category	Input modules			
Submodule ID=IDS_2: Actual GCF 1				
Submodule Ident Number	0x00000002			
Information	Contains the actual Gas Correction Factor (GCF) for Pirani sensor.			
I&M 5 Supported	<input type="checkbox"/> No			
Cyclic Input Data				Item consistency
Name	Data Type	Display as Bits	Subordinate	Length [Bytes]
Actual GCF 1	Unsigned16	<input type="checkbox"/> No	<input type="checkbox"/> No	

Actual GCF 1: Contains the actual Gas Correction Factor (GCF) for Pirani sensor of all Smartline transmitters.

Type	Data	Description
VSR/VCR VSP/VCP VSL/VCL VSM VSH	0x0014 – 0x0320 (20 – 800)	
VSI	0x0000 (0)	Fixed

2.1.4 Actual GCF 2

Module ID=IDM_3: Actual GCF 2				
Module Ident Number	0x00020000			
Information	Contains the actual Gas Correction Factor (GCF) for hot or cold cathode (0 if no such sensor).			
Category	Input modules			
Submodule ID=IDS_3: Actual GCF 2				
Submodule Ident Number	0x00000003			
I&M 5 Supported	<input type="checkbox"/> No			
Cyclic Input Data				Item consistency
Name	Data Type	Display as Bits	Subordinate	Length [Bytes]
Actual GCF 2	Unsigned16	<input type="checkbox"/> No	<input type="checkbox"/> No	

Actual GCF 2: Contains the actual Gas Correction Factor (GCF) for hot or cold cathode of Smartline transmitters.

Type	Data	Description
VSR/VCR VSP/VCP VSL/VCL	0x0000 (0)	Fixed
VSM/VSJ	0x0014 – 0x0320 (20 – 800)	Cold cathode
VSH	0x0014 – 0x0320 (20 – 800)	Hot cathode

2.1.5 Transmitter Status and Type

Module ID=IDM_4: Transmitter Status and Type				
Module Ident Number	0x00010000			
Information	Contains information about Status and Type of the transmitter.			
Category	Input modules			
Submodule ID=IDS_4: Transmitter Status and Type				
Submodule Ident Number	0x00000004			
I&M 5 Supported	<input type="checkbox"/> No			
Cyclic Input Data				Item consistency
Name	Data Type	Display as Bits	Subordinate	Length [Bytes]
Transmitter Status and Type	OctetString	Bit 0: Sensor Type Bit 1: Sensor Type Bit 2: Sensor Type Bit 3: DeGas active Bit 4: High vacuum cathode inactive Bit 5: Spare Filament Bit 6: Sensor Switch Mode Bit 7: Sensor Switch Mode	<input type="checkbox"/> No	1

Bit 0-2: Sensor Type: Contains the Smartline transmitter type

Type	Data
VSR/VCR	0x1 (1)
VSP	0x2 (2)
VSM	0x3 (3)
VSH	0x4 (4)
VCP	0x5 (5)
VSI	0x6 (6)
VSL/VCL	0x7 (7)

Bit 3: DeGas active: Indicates the status of DeGas.

Type	Data	Description
VSR/VCR VSP/VCP VSL/VCL VSM/VSI	0x0 (0)	Fixed
VSH	0x0 (0)	Degas is inactive (default)
	0x1 (1)	Degas is active

Bit 4: High vacuum cathode inactive: For certain vacuum processes it may be favored to suppress the start of the hot cathode (VSH) or cold cathode (VSM/VSI) sensor, which is automatically controlled by the transducer electronics.

Type	Data	Description
VSR/VCR VSP/VCP VSL/VCL	0x0 (0)	Fixed
VSM/VSI	0x0 (0)	Cold cathode is active (default)
	0x1 (1)	Cold cathode is inactive
VSH	0x0 (0)	Hot cathode is active (default)
	0x1 (1)	Hot cathode is inactive

Bit 5: Spare Filament: VSH transmitters have two filaments. This bit indicates that the VSH transmitter has switched to the spare filament, so filament 1 is depleted.

Type	Data	Description
VSR/VCR VSP/VCP VSL/VCL VSM/VSI	0x0 (0)	Fixed
VSH	0x0 (0)	Filament 1 is active
	0x1 (1)	Filament 2 (spare filament) is active

Bit 6-7: Sensor Switch Mode: By default a combi transmitter (VSR/VCR/VSL/VCL, VSM, VSH) performs a continuous transition between its sensor principles over a pressure range whereupon an assimilation of the sensor signals is carried out. The Sensor Switch Mode contains the actual mode.

Type	Data	Description
VSR/VCR VSL/VCL	0x0 (0)	No transition, direct switch at 1 mbar
	0x1 (1)	Continuous transition between 5 mbar and 15 mbar (default)
	0x3 (3)	Custom transition (if set via serial interface or acyclic data)
VSP/VCP VSI	0x0 (0)	Fixed
VSM	0x0 (0)	No transition, direct switch at 1E-3 mbar
	0x1 (1)	Continuous transition between 1E-3 mbar and 2E-3 mbar (default)
	0x3 (3)	Custom transition (if set via serial interface or acyclic data)
VSH	0x0 (0)	No transition, direct switch at 4E-4 mbar
	0x1 (1)	Continuous transition between 1E-3 mbar and 2E-3 mbar (default)
	0x2 (2)	Continuous transition between 2E-3 mbar and 5E-3 mbar
	0x3 (3)	Custom transition (if set via serial interface or acyclic data)

2.1.6 Transmitter Warnings and Errors

Module ID=IDM_5: Transmitter Warnings and Errors				
Module Ident Number	0x00010000			
Information	Contains Information about Warnings and Errors of the transmitter.			
Category	Input modules			
Submodule ID=IDS_5: Transmitter Warnings and Errors				
Submodule Ident Number	0x00000005			
I&M 5 Supported	No			
Cyclic Input Data				Item consistency
Name	Data Type	Display as Bits	Subordinate	Length [Bytes]
Transmitter Warnings and Errors	OctetString	Bit 0: Warning - Overrange Bit 1: Warning - Underrange Bit 3: Error - Filament 1 defect Bit 4: Error - Filament 2 defect Bit 5: Error - Internal Communication Bit 6: Error - EEPROM failure Bit 7: Error - Sensor defect/stacked out	No	1

Bit 0: Warning – Overrange

Type	Data	Description
all	0x0 (0)	No error
	0x1 (1)	Overrange detected, pressure level exceeds the measurement range. The Actual Pressure will be set to 2E+38.

Bit 1: Warning – Underrange

Type	Data	Description
all	0x0 (0)	No error
	0x1 (1)	Underrange detected, pressure level is lower than the measurement range. The Actual Pressure will be set to 2E-38.

Bit 3: Error – Filament 1 defect

Type	Data	Description
VSR/VCR VSP/VCP VSL/VCL VSM/VSJ	0x0 (0)	Fixed
VSH	0x0 (0)	No error
	0x1 (1)	Filament 1 is defect

Bit 4: Error – Filament 2 defect

Type	Data	Description
VSR/VCR VSP/VCP VSL/VCL VSM/VSJ	0x0 (0)	Fixed
VSH	0x0 (0)	No error
	0x1 (1)	Filament 2 (spare filament) is defect

Bit 5: Error – Internal Communication

Type	Data	Description
all	0x0 (0)	No error
	0x1 (1)	Internal communication error of the transmitter electronics

Bit 6: Error – EEPROM failure

Type	Data	Description
all	0x0 (0)	No error
	0x1 (1)	Failure on EEPROM

Bit 7: Error – Sensor defect/stacked out

Type	Data	Description
all	0x0 (0)	No error
	0x1 (1)	Sensor head is stacked out or defect

2.1.7 Syntax Error

Module ID=IDM_6: Syntax Error				
Module Ident Number	0x00010000			
Information	Contains syntax error information for the last executed command.			
Category	Input modules			
Submodule ID=IDS_6: Syntax Error				
Submodule Ident Number	0x00000006			
I&M 5 Supported	No			
Cyclic Input Data				Item consistency
Name	Data Type	Display as Bits	Subordinate	Length [Bytes]
Syntax Error	OctetString	Bit 2: Error - Sensor Switch Mode, Value mismatch Bit 3: Error - GCF 1, Value mismatch Bit 4: Error - GCF 2, Value mismatch Bit 5: Error - Pressure Adjust, Value mismatch Bit 6: Error - Command not supported Bit 7: Error - Command invalid	No	1

Bit 2: Error – Sensor Switch Mode, Value mismatch

Type	Data	Description
VSP/VCP VSI	0x0 (0)	Fixed
VSR/VCR	0x0 (0)	No error
VSL/VCL VSH VSM	0x1 (1)	The value in Data Sensor Switch Mode is wrong or out of range

Bit 3: Error – GCF 1, Value mismatch

Type	Data	Description
VSI	0x0 (0)	Fixed
VSR/VCR	0x0 (0)	No error
VSP/VCP VSL/VCL VSM VSH	0x1 (1)	The value in Data GCF 1 is wrong or out of range

Bit 4: Error – GCF 2, Value mismatch

Type	Data	Description
VSR/VCR VSP/VCP VSL/VCL	0x0 (0)	Fixed
VSM/VSI	0x0 (0)	No error
VSH	0x1 (1)	The value in Data GCF 2 is wrong or out of range

Bit 5: Error – Pressure Adjust, Value mismatch

Type	Data	Description
all	0x0 (0)	No error
	0x1 (1)	The value in Data Pressure is wrong or out of range

Bit 6: Error – Command not supported

Type	Data	Description
all	0x0 (0)	Command not supported
	0x1 (1)	No error

Bit 7: Error – Command invalid

Type	Data	Description
all	0x0 (0)	No error
	0x1 (1)	Command is invalid and cannot be executed

2.1.8 Command executed

Module ID=IDM_7: Command executed				
Module Ident Number	0x00010000			
Information	Contains the value of the last executed command.			
Category	Input modules			
Submodule ID=IDS_7: Command executed				
Submodule Ident Number	0x00000007			
I&M 5 Supported	<input type="text" value="No"/>			
Cyclic Input Data				Item consistency
Name	Data Type	Display as Bits	Subordinate	Length [Bytes]
Command executed	Unsigned8	<input type="text" value="No"/>	<input type="text" value="No"/>	

Command executed

Type	Data	Description
all		Contains the value of the last executed command that was written in Command

2.2 Output Modules

2.2.1 Adjust Value Pressure

Module ID=IDM_8: Adjust Value Pressure				
Module Ident Number	0x00000004			
Information	Reference pressure for readjustment.			
Category	Output modules			
Submodule ID=IDS_8: Adjust Value Pressure				
Submodule Ident Number	0x00000008			
I&M 5 Supported	<input type="checkbox"/> No			
Cyclic Output Data				Item consistency
Name	Data Type	Display as Bits	Subordinate	Length [Bytes]
Adjust Value Pressure	Float32	<input type="checkbox"/> No	<input type="checkbox"/> No	

Adjust Value Pressure

Type	Data	Description
all	Var.	Contains a pressure value as 32bit Real

2.2.2 Set Data GCF 1

Module ID=IDM_9: Set Data GCF 1				
Module Ident Number	0x00000002			
Information	New value for the Gas Correction Factor (GCF), used for Pirani sensor (ignored if no such sensor).			
Category	Output modules			
Submodule ID=IDS_9: Set Data GCF 1				
Submodule Ident Number	0x00000009			
I&M 5 Supported	<input type="checkbox"/> No			
Cyclic Output Data				Item consistency
Name	Data Type	Display as Bits	Subordinate	Length [Bytes]
Set Data GCF 1	Unsigned16	<input type="checkbox"/> No	<input type="checkbox"/> No	

Set Data GCF 1

Type	Data	Description
VSI		Value will be ignored
VSR/VCR VSP/VCP VSL/VCL VSM VSH	0x0014 – 0x0320 (20 – 800)	New value for the GCF 1, used for Pirani sensor (default: 100)

2.2.3 Set Data GCF 2

Module ID=IDM_10: Set Data GCF 2				
Module Ident Number	0x00000002			
Information	New value for the Gas Correction Factor (GCF), used for hot cathode or cold cathode (ignored if no such sensor).			
Category	Output modules			
Submodule ID=IDS_10: Set Data GCF 2				
Submodule Ident Number	0x0000000A			
I&M 5 Supported	No			
Cyclic Output Data				Item consistency
Name	Data Type	Display as Bits	Subordinate	Length [Bytes]
Set Data GCF 2	Unsigned16	No	No	

Set Data GCF 2

Type	Data	Description
VSR/VCR VSP/VCP VSL/VCL		Value will be ignored
VSM/VSJ VSH	0x0014 – 0x0320 (20 – 800)	New value for the GCF 2, used for hot cathode and cold cathode (default: 100)

2.2.4 Set Data Sensor Switch Mode

Module ID=IDM_11: Set Data Sensor Switch Mode				
Module Ident Number	0x00000001			
Information	The set value determines the mode of the sensor transition.			
Category	Output modules			
Submodule ID=IDS_11: Set Data Sensor Switch Mode				
Submodule Ident Number	0x0000000B			
I&M 5 Supported	<input type="checkbox"/> No			
Cyclic Output Data				Item consistency
Name	Data Type	Display as Bits	Subordinate	Length [Bytes]
Set Data Sensor Switch Mode	Unsigned8	<input type="checkbox"/> No	<input type="checkbox"/> No	

Set Data Sensor Switch Mode

Type	Data	Description
VSR/VCR	0x0 (0)	No transition, direct switch at 1 mbar
VSL/VCL	0x1 (1)	Continuous transition between 5 mbar and 15 mbar (default)
VSP/VCP VSI	-	VSP/VCP, VSI has no transition
VSM	0x0 (0)	No transition, direct switch at 1E-3 mbar
	0x1 (1)	Continuous transition between 1E-3 mbar and 2E-3 mbar (default)
VSH	0x0 (0)	No transition, direct switch at 4E-4 mbar
	0x1 (1)	Continuous transition between 1E-3 mbar and 2E-3 mbar (default)
	0x2 (2)	Continuous transition between 2E-3 mbar and 5E-3 mbar

Note: A custom transition (0x3) can be set via communication protocol V2 (see section [3.8](#)).

2.2.5 Command

Module ID=IDM_12: Command				
Module Ident Number	0x00000001			
Information	Command to be executed.			
Category	Output modules			
Submodule ID=IDS_12: Command				
Submodule Ident Number	0x0000000C			
I&M 5 Supported	<input type="text" value="No"/>			
Cyclic Output Data				Item consistency
Name	Data Type	Display as Bits	Subordinate	Length [Bytes]
Command	Unsigned8	<input type="text" value="No"/>	<input type="text" value="No"/>	

Command

Type	Data	Description
all	0x00 (0)	Zero Command
	0x01 (1)	Adjust High Vacuum
	0x02 (2)	Adjust Atmospheric Pressure
	0x03 (3)	Set Gas Correction Factors (GCF)
VSR/VCR	0x39 (57)	Set Sensor Switch Mode
VSP/VCP	-	No special VSP/VCP commands
VSL/VCL	0x04 (4)	Adjust Relative Pressure
	0x39 (57)	Set Sensor Switch Mode
VSM/VS1	0x46 (70)	Activate Cold Cathode
	0x47 (71)	Deactivate Cold Cathode
VSM	0x4D (77)	Set Sensor Switch Mode
VSH	0x50 (80)	Active Hot Cathode
	0x51 (81)	Deactivate Hot Cathode
	0x55 (85)	Activate DeGas
	0x56 (86)	Deactivate DeGas
	0x57 (87)	Set Sensor Switch Mode

3 Commands

3.1 Command List

All commands are separated into two groups:

- General Commands, that are valid for all Smartline transmitter
- Commands, that are valid only for a specific transmitter

Rules for commands:

- Each command will be executed only once.
- Always the last executed command will be written into Command executed.

Type	Data	Name
all	0x00 (0)	Zero Command
	0x01 (1)	Adjust High Vacuum
	0x02 (2)	Adjust Atmospheric Pressure
	0x03 (3)	Set Gas Correction Factors (GCF)
VSR/VCR	0x39 (57)	Set Sensor Switch Mode
VSP/VCP	-	No special VSP commands
VSL/VCL	0x04 (4)	Adjust Relative Pressure
	0x39 (57)	Set Sensor Switch Mode
VSM/VSJ	0x46 (70)	Activate Cold Cathode
	0x47 (71)	Deactivate Cold Cathode
VSM	0x4D (77)	Set Sensor Switch Mode
VSH	0x50 (80)	Active Hot Cathode
	0x51 (81)	Deactivate Hot Cathode
	0x55 (85)	Activate DeGas
	0x56 (86)	Deactivate DeGas
	0x57 (87)	Set Sensor Switch Mode

3.2 General Command Chain for all Smartline Transmitter

3.2.1 0x00 (0) – Zero Command

Type	Chain	Name	Data	Description
all	1.	Zero Command	0x00 (0)	Clear Command executed, allow new command

3.2.2 0x01 (1) – Adjust High Vacuum

Type	Chain	Name	Data	Description
all	1.	Zero Command	0x00 (0)	Mandatory if not 0x00
	2.	Data Pressure	0x00000000 (0) *	Mandatory
	3.	Command	0x01 (1)	Adjust high vacuum

* Adjustments at a certain reference pressure p (only on VSR/VCR/VSP/VCP/VSL/VCL) can be executed via communication protocol V2 (see section [3.8](#)).

3.2.3 0x02 (2) – Adjust Atmospheric Pressure

Type	Chain	Name	Data	Description
VSR/VCR VSL/VCL	1.	Zero Command	0x00 (0)	Mandatory if not 0x00
	2.	Data Pressure	variable	Actual atmospheric pressure
	3.	Command	0x02 (2)	Adjust atmospheric pressure
VSP/VCP VSM VSH	1.	Zero Command	0x00 (0)	Mandatory if not 0x00
	2.	Data Pressure	0x447A0000 (1000)	1000 mbar
	3.	Command	0x02 (2)	Adjust atmospheric pressure

3.2.4 0x03 (3) – Set Gas Correction Factors

Type	Chain	Name	Data	Description
VSR/VCR VSP/VCP VSL/VCL	1.	Zero Command	0x00 (0)	Mandatory if not 0x00
	2.	Data GCF 1 Pirani	0x0014 (20) – 0x0320 (800)	Gas Correction Factor for Pirani
	3.	Data GCF 2 CC / BA	d.c.	Value will be ignored
	4.	Command	0x03 (3)	Set GCF factors
VSM VSH	1.	Zero Command	0x00 (0)	Mandatory if not 0x00
	2.	Data GCF 1 Pirani	0x0014 (20) – 0x0320 (800)	Gas Correction Factor for Pirani
	3.	Data GCF 2 CC / BA	0x0014 (20) – 0x0320 (800)	Gas Correction Factor for Cold Cathode (CC) or Hot Cathode (BA)
	4.	Command	0x03 (3)	Set GCF factors
VSI	1.	Zero Command	0x00 (0)	Mandatory if not 0x00
	2.	Data GCF 1 Pirani	d.c.	Value will be ignored
	3.	Data GCF 2 CC / BA	0x0014 (20) – 0x0320 (800)	Gas Correction Factor for Cold Cathode (CC)
	4.	Command	0x03 (3)	Set GCF factors

3.3 VSR/VCR Commands

3.3.1 0x39 (57) – Set Sensor Switch Mode

Chain	Name	Data	Description
1.	Zero Command	0x00 (0)	Mandatory if not 0x00
2.	Data Sensor Switch Mode	0x0 (0) or 0x1 (1) *	
3.	Command	0x39 (57)	Set sensor switch mode

3.4 VSL/VCL Commands

3.4.1 0x04 (4) – Adjust Relative Pressure

Chain	Name	Data	Description
1.	Zero Command	0x00 (0)	Mandatory if not 0x00
2.	Data Pressure	d.c.	Value will be ignored
3.	Command	0x04 (4)	Adjust relative pressure to zero

3.4.2 0x39 (57) – Set Sensor Switch Mode

Chain	Name	Data	Description
1.	Zero Command	0x00 (0)	Mandatory if not 0x00
2.	Data Sensor Switch Mode	0x0 (0) or 0x1 (1) *	
3.	Command	0x39 (57)	Set sensor switch mode

3.5 VSM/VSJ Commands

3.5.1 0x46 (70) – Activate Cold Cathode

Chain	Name	Data	Description
1.	Zero Command	0x00 (0)	Mandatory if not 0x00
2.	Command	0x46 (70)	Activate cold cathode

3.5.2 0x47 (71) – Deactivate Cold Cathode

Chain	Name	Data	Description
1.	Zero Command	0x00 (0)	Mandatory if not 0x00
2.	Command	0x47 (71)	Deactivate cold cathode

3.6 VSM Commands

3.6.1 0x4D (77) – Set Sensor Switch Mode

Chain	Name	Data	Description
1.	Zero Command	0x00 (0)	Mandatory if not 0x00
2.	Data Sensor Switch Mode	0x0 (0) or 0x1 (1) *	
3.	Command	0x4D (77)	Set sensor switch mode

3.7 VSH Commands

3.7.1 0x50 (80) – Activate Hot Cathode

Chain	Name	Data	Description
1.	Zero Command	0x00 (0)	Mandatory if not 0x00
2.	Command	0x50 (80)	Activate hot cathode

3.7.2 0x51 (81) – Deactivate Hot Cathode

Chain	Name	Data	Description
1.	Zero Command	0x00 (0)	Mandatory if not 0x00
2.	Command	0x51 (81)	Deactivate hot cathode

3.7.3 0x55 (85) – Activate DeGas

Chain	Name	Data	Description
1.	Zero Command	0x00 (0)	Mandatory if not 0x00
2.	Command	0x55 (85)	Activate DeGas

3.7.4 0x56 (86) – Deactivate DeGas

Chain	Name	Data	Description
1.	Zero Command	0x00 (0)	Mandatory if not 0x00
2.	Command	0x56 (86)	Deactivate DeGas

3.7.5 0x57 (87) – Set Sensor Switch Mode

Chain	Name	Data	Description
1.	Zero Command	0x00 (0)	Mandatory if not 0x00
2.	Data Sensor Switch Mode	0x0 (0), 0x1 (1) or 0x2 (2) *	
3.	Command	0x57 (87)	Set sensor switch mode

* A custom transition (0x3) can be set via communication protocol V2 (see section [3.8](#)).

3.8 Acyclic Data Exchange

Using acyclic data records, the limited range of commands in cyclic data communication to configure a gauge is now extended to all commands available (see the corresponding transmitter manual). For sending and receiving acyclic data records a simplified version of the Thyracont communication protocol V2 needs to be applied. The protocol documentation with more information regarding the commands, as well as a demo on how to use the acyclic data exchange with our PROFINET gauges, can be found on our homepage (see also chapter [6](#)). The following table shows the parameters to apply in a project planning tool for using the acyclic data exchange:

	Write Record	Read Record
ID	IDM_1 (Actual Pressure)	IDM_1 (Actual Pressure)
INDEX	1	1
LEN / MLEN	Number of bytes to be transmitted (max. 104)	110 (max. number of bytes allowed to be transmitted)
RECORD	See Thyracont communication protocol V2	See Thyracont communication protocol V2

In general, each command (independent of writing data to, or reading data from the gauge) needs to be sent via "Write Record". The response of the device can then be read out via "Read Record" within **6 seconds**. After this time, the response will be a PROFINET timeout error.

In case of configuration commands, it is recommended to evaluate the device response for success or error.

Note: Applying acyclic data records decreases the refresh rate of the cyclic data records by factor 2.

4 Device Diagnostics

4.1 Manufacturer Specific Channel Diagnosis

Value (Hex)	Content
0x0013	Internal communication error The internal communication could not be reset automatically. The device must be switched off and back on again. If this warning occurs frequently, please inform the service.
0x001B	Sensor error The sensor was stacked out, or is defect and must be exchanged.

5 Web Interface

The device offers a small web interface with basic information about the gauge and PROFINET interface, and the possibility to update the PROFINET firmware. It can be accessed by entering its assigned IP address in your web browser. In case of PROFINET firmware updates please contact Thyracont for more information.

6 Additional Files (GSDML, Documentation)

You can download the GSDML files and related documents (transmitter, communication protocol) from the Thyracont webpage:

1. Open Thyracont webpage <https://thyracont-vacuum.com/>
2. Browse to Support → [Download Center](#)
3. Section "Smartline - Intelligent Vacuum Measurement"
 - a. Transmitter manuals (PDF)
 - b. GSDML files (ZIP)
4. Section "Software and Apps, protocols, drivers and other"
 - a. Communication manuals (PDF)

7 Document History

Date	Version	Comment	Script-Revision Number	Firmware Version
2019-01-09	1.0	Initial Release v1.0	V 3.1.2_0615_1	3.1.3
2020-02-17	1.1	VSL PN communication manual added	V 3.1.3	3.1.3
2021-06-25	1.2	VCL, VCR added	V 3.1.3	3.1.3
2021-xx-xx	1.3	Fixes	V 3.1.3	3.1.3
2023-02-22	2.0	Removed parts of old PROFINET interface; Added parts for new PROFINET interface and Acyclic Data Exchange	-	1.0.0.1 (5.4.0.6)
2023-11-22	2.1	Added chapter "Web Interface"		
2025-06-03	2.2	Some corrections		

8 License

PROFINET® is a registered trademark of Profibus and PROFINET International (PI).